[Important Instruction]
NEC Express5800/120Bb-6, 120Bb-d6, 120Bb-m6

Thank you for choosing NEC Express5800 series servers.

This document describes important instructions for use in the User's Guide. Please read all the instructions below and observe caution when using your system. If you don't apply this, it may cause your system to disable communication.
Keep this paper carefully for quick reference.

Setting LAN driver

Please change the setting of LAN driver. See bellow.

<Operating system affected>

Microsoft Windows Server 2003 Enterprise Edition + ServicePack1 *
Microsoft Windows Server 2003 Standard Edition + ServicePack1 *
Microsoft Windows Server 2003 Enterprise x64 Edition *
Microsoft Windows Server 2003 Standard x64 Edition *
Microsoft Windows Server 2003 R2 Enterprise Edition
Microsoft Windows Server 2003 R2 Standard Edition
Microsoft Windows Server 2003 R2 Enterprise x64 Edition
Microsoft Windows Server 2003 R2 Standard x64 Edition

* When the installation of Microsoft Windows Server 2003 Scalable Networking Pack has finished.

<Setting>

1. Open the [Device Manager].
2. Double-click [Intel(R) PRO…] in the list.
3. Click the [Advanced] tab.
4. Change the setting of "Receive-Side Scaling" (RSS) from "Enabled" to "Disabled".
5. Click the [OK] button.

NOTE: Please apply this to all LAN port on your system. Two LAN ports exist on 120Bb-6 and 120Bb-d6, and four LAN ports exist on 120Bb-m6.
If you added LAN port to your system, also apply this to added ports.

＊856-126396-308-00＊